


### SMART SWITCH—DECORATOR PART #: SS-DEC



#### **CLEANING INSTRUCTIONS**



### **ALWAYS**

SYMBOLS AS SHOWN
ON SUBMITTAL AND
CONSTRUCTION
DOCUMENTS

- USE ONLY TOUCHSCREEN SAFE CLEANER AND CLEAN MICROFIBER CLOTH
- DAMPEN THE CLEAN MICROFIBER CLOTH AND WIPE SWITCH
- WIPE THE SWITCH DRY WITH A CLEAN MICROFIBER CLOTH



### **NEVER**

- USE GLASS CLEANER
- SPRAY SWITCH DIRECTLY WITH CLEANER
- USE PAPER TOWELS


FAILURE TO FOLLOW THESE INSTRUCTIONS
WILL DAMAGE THE SWITCH AND VOID THE
WARRANTY

## **TIPS / NOTES**

- MINIMUM CAT 5 CABLE—ENSURE CABLES ARE PLUGGED INTO SMART PORTS OF ROOM MANAGER, SMARTPACK PLUS, OR SMARTPACK. <u>DO NOT</u>
   CONNECT TO BRANCH PORTS.
- MOUNT TO SINGLE GANG JUNCTION BOX OR 4 SQUARE BOX WITH SINGLE GANG MUD RING.



# SMART SWITCH—DECORATOR PART #: SS-DEC



Touché Controls (a Product of ESI Ventures)