

SCREEN INFORMATION


SYMBOLS AS SHOWN
ON SUBMITTAL AND
CONSTRUCTION
DOCUMENTS 



COMMUNICATION ERROR

ISSUE - POWER AND NO COMMUNICATION


- VERIFY SWITCH IS CONNECTED TO BRANCH PORT
- VERIFY CABLING TERMINATION COLOR CODING




WIRING ERROR

ISSUE - NO POWER AND NO COMMUNICATION

- VERIFY SWITCH IS CONNECTED TO BRANCH PORT
- VERIFY CABLING TERMINATION COLOR CODING




ACTIVATION SCREEN



NO ACTION REQUIRED

MOUNTING



TIPS / NOTES

1. FRONT BEZEL
 2. BACK MOUNTING PLATE
 3. STANDARD 1-GANG PLASTER RING MOUNTED ON 4 SQUARE ELECTRICAL BOX - CUT-IN BOX NOT RECOMMENDED
 4. MINIMUM CAT 5 CABLE - ENSURE CABLES ARE PLUGGED INTO BRANCH PORTS OF ROOM MANAGERS - DO NOT CONNECT TO SMART PORTS
- WS-TS-C-XXX IS ONLY COMPATIBLE WITH THE ROOM MANAGER

CLEANING INSTRUCTIONS

ALWAYS

- USE ONLY TOUCHSCREEN SAFE CLEANER AND CLEAN MICROFIBER CLOTH
- DAMPEN THE CLEAN MICROFIBER CLOTH AND WIPE SWITCH
- WIPE THE SWITCH DRY WITH A CLEAN MICROFIBER CLOTH


NEVER

- USE GLASS CLEANER
- SPRAY SWITCH DIRECTLY WITH CLEANER
- USE PAPER TOWELS

FAILURE TO FOLLOW THESE INSTRUCTIONS WILL DAMAGE THE SWITCH AND VOID THE PRODUCT WARRANTY



SYMBOLS AS SHOWN ON SUBMITTAL AND CONSTRUCTION DOCUMENTS



CABLE TYPES			
LINE ID	DESCRIPTION	TYPE	NOTES
	BRANCH	CAT 5 (MIN)	TOTAL BRANCH LENGTH NOT TO EXCEED 1000'