





**PAGE NOTES:**

- ① TOUCH SCREEN USER INTERFACE
- ② MODULE STATUS INDICATOR
- ③ COMMUNICATION STATUS INDICATOR
- ④ REMOVABLE PANEL COVERS FOR FIELD WIRING
- ⑤ COMMUNICATION INTERFACE COVER (BLACK-DO NOT REMOVE)
- ⑥ RELAY OR DIMMING MODULES
- ⑦ COMMUNICATION INTERFACE CARD (DO NOT REMOVE)
- ⑧ INTERCONNECT CARD (DO NOT REMOVE)

**FRONT VIEWS**

**INSIDE VIEWS**






**RD-32 RELAY PANEL**  
SCALE: N.T.S

**RD-48 RELAY PANEL**  
SCALE: N.T.S

**RD-32 RELAY PANEL**  
SCALE: N.T.S

**RD-48 RELAY PANEL**  
SCALE: N.T.S

PART#	RD-48 & RD-32	
DESC.	RD (1 OF 3)	
DWG#	1-RD	
DATE:	10/16/15	REV. 16-4
		DRAWING BY: TDP



**RD-32 RELAY PANEL DIMENSIONS**  
SCALE: N.T.S

**RD-48 RELAY PANEL DIMENSIONS**  
SCALE: N.T.S

**RD PANEL WIRING**  
SCALE: N.T.S


PART#	RD-48 & RD-32	
DESC.	RD (2 OF 3)	
DWG#	2-RD	
DATE:	10/16/15	REV. 16-4
DRAWING BY:		TDP

www.touchecontrols.com  
phone: 1-888-841-4356

# Touché

LIGHTING CONTROL

TOP OF RD PANEL



RIGHT SIDE MODULE  
INSTALLATION

LEFT SIDE MODULE  
INSTALLATION



RD PANEL MODULE WIRING  
SCALE: N.T.S

PART#	RD-48 & RD-32	
DESC.	RD (3 OF 3)	
DWG#	3-RD	
DATE:	10/16/15	REV. 16-4
DRAWING BY:	TDP	

www.touchecontrols.com  
phone: 1-888-841-4356

**Touché**  
LIGHTING CONTROL